



Unscrew the top cover to reveal the brass click-clack bracket. A stainless steel bracket will have also been included within the pack which can be switched with the brass bracket to ensure the waste stays open - usually used for basins without overflows.



Unscrew the lower half of the waste by twisting anti-clockwise until the lower half is completely separated as seen in step 4.



Apply a layer of silicone on top of and under the rubber ring to ensure a water tight seal. Place the upper half within a basin hole and twist the lower half clockwise back on to the threaded screw from underneath.