

How to punch tap holes

Only drill Tap hole FROM TOP FACE

1. Decide on the pre-punched tap holes you require.
2. Measure to find the centre of the pre-punched tap hole required and cover the area with masking tape.
3. Using a centre punch, crack the glaze in the centre of the required hole.
Caution - Ensure that the sink is supported under the hole to be knocked out.
4. Using a No. 8 masonry drill, carefully drill a small pilot hole from the top.
NB. Only drill one small hole
5. You can then proceed to enlarge the hole to the required size by carefully using your hammer with the centre punch.
6. A cut-out of the appropriate size should be made and the sink inserted using a clear mastic sealant around the perimeter to avoid water ingress.