
# bath panels



## Neptune bath panel



### to specify/order:

Please use the product reference shown below.

## neptune

# (dedicated to neptune baths)

Design panel:

Front panel (for 1700mm baths) NL7700WH
Front panel (for 1500mm baths) NL7500WH
End panel (for 700 mm wide baths) NL7701WH

#### material

Moulded styrene 1.8mm thick.

#### colours


White WH.

#### fixings

Secured under bath rim using clips supplied with bath and screwed to timber blocks (not provided).



Omnifit bath panels



# to specify/order:

Please use the product reference shown below.

# omnifit

Front panel (for 1700mm baths)
PP2171WH
Front panel (for 1524mm baths)
End panel
(for baths up to 800mm wide)
PP2172WH

#### material

Moulded styrene 2mm thick.

#### colours

White WH.

#### fixings

Secured under bath rim using clips supplied with bath and screwed to timber blocks (not provided).

All measurements shown are in millimetres. Drawing sizes are not to scale.







