

## CORNER BATH FIXING INSTRUCTIONS

**NOTE : BEFORE FIXING** - Remove all protective covering & check product carefully.

Check that colour matches pottery, both in daylight & under electrical lighting (some types of lighting can create a change of colour). Obtain acceptance and assurance by the householder. Any claim for wrong colour and / or obvious fault(s) will **NOT** be accepted by the manufacturers **AFTER FIXING**, or with any additional work (whirlpools etc) having being carried out by any person than Trojan Plastics Limited.

### PLEASE READ THE INSTRUCTIONS THOROUGHLY - PRIOR TO FIXING BATH

1. Check fittings pack that components are complete.
2. Turn Bath upside down, taking care to protect the surface, screws on the channel pieces and the centre foot bracket.
3. Fit the five feet, leaving them loose for ease of adjustment, turn the bath over and adjust to panel height, making sure the top of the bath is level. Tighten the nuts which secure the five feet to the channel pieces and centre foot.
4. Mark the height to the underside of the bath rim and fit wooden battens (not supplied) along each wall, leaving 150mm clear to the end of the bath.
5. Fit taps and waste.
6. Place bath in position on the wooden battens and screw the wall brackets to the bath (as per diagram) finally secure wall brackets to wall (as shown) and screw feet to floor (fig 1).
7. If a styrene panel is used screw on the four panel clips (fig 2).

### CHECK LIST

- |                           |                              |
|---------------------------|------------------------------|
| 2 x Channels              | 1 x Centre bracket           |
| 1 x M10 x 120mm Bath Foot | 4 x M10 Adjustable Bath Feet |
| C/W 2 Nuts                | C/W 3 Nuts                   |
| 2 x Wall Brackets         | 4 x Panel Clips              |
|                           | 16 x No 8 5/8 " Wood Screws  |

