


Installation Instructions & User Guide

Please leave these instructions with the end user

Product Code: SK INXSQ1.5 SU (D1)


Tools You'll Need

x1 □















x1 □

Pack Contents

Safety Glasses









x10 □

All products manufactured and supplied by Bristan are safe provided they are installed, used correctly and receive regular maintenance in accordance with these instructions.

This product has been tested to the Water Regulations Advisory Scheme (WRAS) and satisfies the requirements of the Water Supply (Water Fittings) Regulations 1999 and current bylaws. For full Installation Requirements & Notes (IRN) please visit wras.co.uk/directory.

Isolation valves must be fitted to the inlet water supplies to ensure ease of future maintenance.

Before installing these taps the water supply must be thoroughly flushed in order to remove any swarf, solder etc.

This product must not be modified in any way as this will invalidate

Before drilling into walls, check that there are no hidden electrical wires, cables or water supply pipes. This can be checked with the aid of an electronic detector.

If power tools are used do not forget to:


- Wear eve protection
- Unplug equipment after use

If in doubt, contact a registered plumber or your Local Water Authority or the Secretary of the Institute of Plumbing, address as follows:-

The Institute of Plumbing, 64 Station Lane. Hornchurch,

RM12 6NB, Tel: 01708 472791


Dimensions



Inlet Connections




Waste Connection Size: G 1 1/2"



Min Worktop Thickness: 30mm Max Worktop Thickness: 40mm









To replace any spare parts

for your sink, why not

scan the QR Code or REMEMBER visit www.bristan.com and search for

Spare Parts


The waste pipes can be cut to size to fit the sink

Connect the waste to the domestic waste supply.

There is an optional connection for a water appliance. Please see the Maintenance section for


You can now fit your EasyFit Tap. Please refer to those instructions to check the Pack Contents and Tap Maintenance.





reinforce, or change the orientation of the sink. follow the steps overleaf.

REMEMBER Make sure the base is centralised when viewed from the front of the tap



Screw the Overflow Connection into place and connect to the waste body. Carefully turn the sink upside-down.



Fit the waste bodies to the sink. Secure in place with the screw.

Ensuring it's straight, place the

Cutter Guide on the worktop

and draw around the dotted line.

Drill and cut the hole.



Installation



worktop is thinner than





Attach the clamps to the sink, ensuring that they lock in place. Stick the sealing strip along the outer ridge, ensuring it is flush to the sink.





more details.


General Cleaning

Bristan products are made from high quality stainless steel, or glass conforming to BS EN 12150. Your sink should be regularly cleaned with warm water, a mild pH-neutral liquid soap, and dried with a soft cloth. Any residues from soap, food, toiletries etc. should be rinsed off straight after use.

Household bleaches and cleaners contain harsh chemicals and may damage the surface finish. Avoid using abrasive cloths, scouring pads, scrub sponges, steel wool or anything similar. Avoid scraping the sink basin or draining board with utensils or dropping heavy/sharp objects on to the sink surface. Do not place hot objects directly on to the sink.







Symptom	Cause(s)	Remedy
Sink is leaking	Loose waste connections	Check waste connections for any leaks, ensuring all O-rings are in place.
	Seal around the sink edge/plug lets water through	Add extra silicon sealant to those edges to ensure a water tight seal.
	Sink leaking from the overflow	Check the overflow seal and connections for damage. Ensure the screw is tightened.
Water isn't draining from the sink	Sink is blocked.	Refer to the Maintenance Section for Unblocking the Sink. If no blockage is found in the waste pipework please contact your local Plumber for guidance.
Clamps do not grip the worktop	Worktop is under 30mm	Use a strong material e.g. wood to place under the worktop in order for the clamps to grip.
Wobbly Tap/ Sink is Flexing	Tap grub screws are not tight enough at the base	Ensure the grub screws are fully tightened against the base. See your EasyFit Tap Instructions.
	Extra security may be required to support the tap base.	Refer to the Alternative Installation steps in order t fit the Reinforcing Plate.

Notes

At Bristan, we want to make things as easy as possible for our customers. That's why we offer solid guarantees or all our products, effective from the date of purchase, to give you peace of mind.

To start your free guarantee simply scan the QR code and register your product. Alternatively visit www.bristan.com/register.

For any other queries, please call our Customer Service on 0330 026 6273 where our expert team of advisors will be able to offer you any help and advice.

For full guarantee terms and conditions visit www.bristan.com/guarantees.

