

floor are perpendicular to the bottom of the bath. N.B. It is important that the cradle legs, when finally fixed to the

6. Secure bath to walls with wall clips (J) in 2 positions, as shown.

5. Place bath in situ and screw foot clamps to floor.




cradles. bushed ends (H) of the adjustable feet into the adjustable feet. Screw the 3. Screw nuts (G) onto the



path. cause damage to the Tighter than that, will finger tight only. Tighten the wing nuts **NOTE!**

nut. Tighten nut (D) to 3.0the flat washer and the wing to be positioned between Please note locking washer (D) and locking washer (E). and secure with flat washer 2. Place cradles (C) in position

plastic pads (B) over lugs. in bath lugs and place stols ofni (A) atlod noitisoq 1. With the bath upside down



against bushes (H). (5) stun nogsxad gninathgit lock feet in position by lightly from floor to top of bath) and and height (normally 540mm 4. Adjust feet for correct level



FLAT PACK CRADLE For Porcelain Enamel Baths



Edghehill Drive, Warwick, CV34 6NH

05/04