



PREMIUM **CORNER ENTRY** SHOWER ENCLOSURE  
**FITTING INSTRUCTIONS**



**heatandplumb**  
[.com](http://heatandplumb.com)















Tel: 0844 855 3222 email: [sales@heatandplumb.com](mailto:sales@heatandplumb.com)

Page 1




# PRODUCT PARTS

The following pictures show the parts and the quantities included for this product. Please ensure that these parts are included before you start installing...




# INSTALLATION PROCEDURE DIAGRAMS



# INSTALLATION PROCEDURE INSTRUCTIONS

- 1: Install wall profiles level in upright position using screws No. 7 (see Fig. 5)
- 2: Build frame by attaching top and bottom profiles (No. 1) to fixed panels (No. 12) using fixing screws supplied(No. 8) securely on each corner make sure gaskets are fully inserted and pushed home as not fully inserted will result in doors not clipping into position (see Fig. 3)
- 3: Hang doors (No. 13) to top profile using adjustment to check for initial smooth running, re move to fix frame to wall profiles(doors can be reinstalled after frame is secured)
- 4: Fix frame to wall profiles using screws on inside (see Fig. 6)
- 5: Fix handles (No.14) to doors (see Fig. 9)
- 6: Hang doors onto frame and adjust for smooth running
- 7: Seal door on outside only (wall and between tray) to ensure watertight seal,do not use for 24hours.

**Adjustment:** All doors are designed to run correctly. If this does not occur please make sure gaskets are fully slotted in or use hex nuts on back of top roller to get adjustment



# EASY FIT SYSTEM

