

Shower Screens

User care and cleaning instructions

AKW showering and daily living products have been developed on the basis that they are cleaned regularly using normal domestic bathroom cleaning materials.

Do not use abrasive products, cloths, strong or concentrated acidic or alkaline cleaning materials as these may discolour or otherwise damage the product.

The use of strong or concentrated acidic, alkaline, chlorine or other cleaning materials will invalidate any warranty as this may discolor or otherwise damage the products.

DO NOT place matches, cigarettes or naked flames on or near this product.

Aftercare Instructions

It is important to clean areas such as seals and keep moving parts clear from build up of grime and water deposits to maintain good working order. Dry with a towel to prevent new water spots from forming.

Whenever possible always rinse down the screen, shower, shower rail and curtain after use to remove soap and any other deposits.

After cleaning, the user should always rinse with water and wipe thoroughly with a soft damp cloth to remove any cleaning material residues before drying off.

AKW do not approve or recommend autoclave cleaning of any of the components due to the damage this can cause to the special engineering plastics used in the construction of this product.

Where disinfecting is necessary, standard procedures for disinfecting equipment should be used taking due care and attention to the warnings concerning possible effects of aggressive chemicals on plastics or other surfaces.

*Guarantee for life Conditions - Not covered by any warranty

Damage or defects that result from incorrect installation, improper use, accidental damage or lack of maintenance including the buildup of grime, dirt or limescale and waterborne debris. Damage resulting from inappropriate cleaning or water ingress. Damage or defects that result from repairs, modifications undertaken by unauthorised persons who are not AKW authorised service staff or agents.

The guarantee applies only to manufacturing or material defects and does not apply to normal wear and tear, inappropriate use or accidental damage.

AKW products should be installed by experienced and competent persons using fixings appropriate for the maximum rated user load and selected to suit the condition of the surfaces on which the product is to be attached. The selection of any specific fixings must be made by the installer based upon the requirements for each individual installation. Power showers should not be specified for use with AKW shower trays and screens.

Silverdale ® Screens & Clear Plastic Screen Doors.

DO NOT USE abrasive products, cloths, strong or concentrated acidic or alkaline cleaning materials as these may affect, discolour or otherwise damage the surface finish of the plastic panels.

It is recommended that only AKW screens should be used with AKW shower trays. These products have been designed and manufactured to complement each other. Their use with non AKW products may adversely affect the integrity of the water seal between the shower base and doors.

Orderline

01905 823299

General Enquiries

01905 823298

Technical Help line

01905 560219

technicalenquiries@akw-ltd.co.uk

Fax

01905 823297

Website

www.akw-ltd.co.uk

Quotes & orders email

orders@akw-ltd.co.uk

Enquiries email

sales@akw-ltd.co.uk

Post

AKW, Pointon Way,
Hampton Lovett,
Droitwich Spa,
WR9 0LR



AKW Limited,
Pointon Way, Hampton Lovett
Droitwich Spa, WR9 0LR

13

DoP 07-002-590

PH

EN 14428:2004+A1:2008

What to do if something goes wrong?

In the unlikely event that you should encounter a problem with this product, please contact your local installer and if this does not resolve the issue then contact AKW technical team who will provide further advice and if necessary arrange for our service engineer to visit or discuss our comprehensive after-sales service. As part of our quality and training program calls may be monitored or recorded. None of the foregoing affects your statutory rights.

Failure to install this AKW product in accordance with supplied instructions or the making of unauthorised modifications will invalidate any warranty and will affect product safety.

Option HF and HFW Shower Screens

Installation And User Care Instructions





Always read all the instructions carefully BEFORE installation and leave with the end user for future reference

Choose which screen option cubical is to be installed and read all the steps clearly before installation.

*These screens can be fitted to Multi-Spec trays or trays fitted with a pipe work duct.

+ In addition to fitting the trays as indicated in the catalogue these screens can be fitted to trays with integral or optional pipe work ducts. When fitted to a pipe work duct the extra wide compensators will be required. See separate instructions.





Step 1 - Compensator Installation

Take out adjusting screws from inside of compensator. Place compensator against wall making sure edge of compensator lines up over the inside edge of tray.

For surface mounted trays use the card template to align the outside edge of the compensator to the outside edge of the tray. Fig 1.1
For flush mounted trays use the notch as a guide to align the compensator with the outside edge of the tray. Fig 1.2

Mark off hole position when level. Drill into wall with a No.10 masonry drill bit.
Fit wall plugs and fix compensator with No. 8 x 1 1/2 pan. Fig 1.3




Step 2 - Corner Block Installation

FOR WET FLOOR INSTALLATION ONLY.

Corner block is removable, please ensure that the compensator locking holes are on the inside of the showering area.

Corner blocks must be trimmed to suit altro floor using a heavy pair of scissors or snips then sanded down to give a smooth finish.


See Fig. 2



Step 3 - Compensator and Door/Panel Installation

Fit the Stile cap to the bottom of the panel. Slide panel into outer compensator.

See Fig. 3




Step 4 - Post and Panel Installation

Mark off post and panel position onto the tray or wet floor area, remove post and drill 3mm diameter holes into the tray or wet floor area.

Fit post block with No. 6 x 1 pan screw and then refit the post. Then refit the side panel.


See Fig. 4



Step 5 - Secure Panel

Drill 3.5mm diameter holes through holes in outer compensators into the panel and then fit the locking screws with uniscrew caps to the inside of the screens.

See Fig. 5



**CURTAIN RAILS ARE SUPPLIED OVERSIZE AND WILL NEED CUTTING TO SIZE.
PLEASE FIT CORRECT AMOUNT OF HOOKS AND GLIDERS TO RAIL BEFORE INSTALLATION**

Step 6 - Secure Rail


Fit end stop to rail, then check rail is horizontal using a builder's level.

Drill into panel using 3mm drill bit and No.6 x 1 1/2 pan head screw with spacers between rail and panel.

Please note that screws are to be fitted with uniscrew caps.

Fit all panel stile and compensator end caps.

See Fig. 6




Step 7 - Curtain Rail

Curtain rails are to be positioned on the inside of screens.

When rail is level, mark off curtain rail bracket hole positions, then drill into wall with a No.10 masonry drill bit. Fit red plugs and then fit with a No.8 x 1 1/2 and cover caps.


See Fig. 7 and 8



Step 8 - Attach Curtain Rail Post

When rail and post are level using bracket supplied, drill into post and rail using a 3.5mm drill bit and fasten with No. 8 x 1/2 pan and finish off with cover caps.

See Fig. 9



Step 9 - Final Checks

Ensure all screws are fully tightened and ensure all panel stile caps and cover caps are fitted.

See Fig. 10

Silicone seal all joints between framework and tray and framework and wall on both sides. Complete final checks.

See Fig. 11

