Warranty Information

Proof of purchase will be required.

The guarantee does not cover faults or damage caused by incorrect installation and/or maintenance, ordinary wear and tear, water composition, etc.

*Please see www.methven.com for full terms and conditions of warranty.

Cleaning

Your product has a high-quality finish and should be treated with care to preserve the visible surfaces. Never use abrasives or abrasive cleaning agents to clean this product. Clean regularly with contamination free warm water and a damp soft cloth. Do not use products containing chlorine bleach or hydrochloric acid as these can damage the product.

We have a policy of continuous improvement and reserve the right to change specifications without notice.

METHVEN UK LIMITED
METHVEN EXPERIENCE CENTRE
3/3A STONE CROSS COURT
YEW TREE WAY
GOLBORNE
WARRINGTON
WA3 3JD
UNITED KINGDOM

INST-ELSMCP-V1 13.10.2020

TEL: 0800 195 1602 FAX: 0844 406 8690

EMAIL: sales@uk.methven.com

www.deva-uk.com www.methven.com

Ellesmere Flexi Sink Mixer

ELSMCP

Installation Guide

Technical Specification Working Pressure:

Min: 0.5 Bar Max: 5.0 Bar

Operating Temperature:

Hot: 65°C Cold: 5°C

Inlet Connections:

1/2" BSP

Features:

- · On trend design perfectly complements contemporary kitchens
- Pull down nozzle is ideal for rinsing pots and pans
- Lever handle is simple to use for all the family – tilt and turn temperature & flow control
- · Fitted with a ceramic cartridge for easy operation and longevity
- · Optimised to operate at 6 litres per minute in order to save water
- · Chrome plated finish with matt black tube
- · In full colour packaging







Contents

Cleaning

Congratulations on your purchase of your new Methven Sink Mixer. Our fitting instructions have been created with you in mind to provide you with all the information you require and, if you need any further help, please don't hesitate to contact our customer care team on 0800 195 1602.

General Safety Information 3

Line Drawing 3

Product Breakdown 4

Product Breakdown 4

Installation Requirements 6

Installation 7

Warranty Information 8

8

Troubleshooting

| Symptom | Cause(s) | Resolution | |
|-------------------------------------|---|--|--|
| Mixer not | Mains Water supply turned off | Turn on the mains water supply | |
| turning on | Closed isolation valve | Open isolation valve | |
| No hot water | Cold override | Check if the pressure is balanced. Fit | |
| | | pressure equalising valve. | |
| Low Flow Rate/No Flow | Water supply failure | Investigate water supply, check plumbing | |
| | | and heating system for any faults | |
| | Partially closed isolation valve | Open isolation valve | |
| | Air lock or partial blockage in the supply | Flush through pipework to ensure | |
| | pipework or hoses | removal of debris and any airlocks. | |
| | Water being drawn off elseware causing | | |
| | pressure changes or instantaneous boiler | Try not to use other water outlets when | |
| | temperature changes. Ensure minimum | using the mixer | |
| | pressure is being met. | | |
| Water dripping from the mixer | This is normal for a short time after using | This is due to residual water tension, the | |
| | the mixer | build up of water in the mixer spout. | |
| | If water continues to drip, possible issue | Please contact our customer care team. | |
| | with the flow control cartridge. | Please contact our customer care team. | |
| Movement of fitted mixer | Fixing kit loose | Ensure fixing kit nut is sufficiently | |
| | | tightened. | |
| | Extra support may be required depending | Please contact customer care to purchase | |
| | on the surface the tap is fitted to. | a under sink mounting triangle | |

Installation Requirements

Before commencing installation of the new product, ensure that the system has been flushed to remove any debris, which could cause damage to the valves and invalidate the warranty.

Installation


- 1, Put the O-Ring (B) into the base ring
- 2, Pass both Flexi Tails (G) through the S.S fixing tub (A) into the tap body, ensuring that the O-Ring on the tail is positioned inside the tap body. Hand tighten, do not use PTFE tape or similar to create the seal.
- 3, Offer the tap up to the hole in the sink
- 4, On the underside of the sink fit the Triangle fixing board (C) rubber gasket (D) and S.S gasket (E) on to the s.s. fixing tub (A)

Note: Plastic Triangle Fixing Board - This should be used on thin work surfaces to help distribute the weight of the tap and provide a thicker mounting surface for the fixing kit to clamp to.


5, Install the plastic fixing nut (F) and fasten on to the s.s. Fixing tub (A) by hand


6, Connect the male end of the tail to the corresponding hot and cold inlets.

7, Reinstate water supply and test for leaks.



Do not stretch or twist hose







Please keep these instructions for future reference and request of replacement parts

General Safety Information

Please read all of the instructions before installation.

Methven recommends this product is installed by a competent person in compliance with all relevant regional regulations.


Remove all packaging and check the components for damage before starting installation.

This product must not be modified in any way as this will invalidate the guarantee.


It is the responsibility of the installer to ensure a waterproof seal is achieved, after installation all connections must be checked for leaks.

All outlets used primarily for personal hygiene shall deliver water at a safe temperature as per regional regulations.

Line Drawing



Check All components are present prior to starting installation.



| Part No | Description | |
|---------|------------------|--|
| 1 | Handle | |
| 2 | Screw | |
| 3 | Indicator | |
| 4 | Cartridge Cap | |
| 5 | Hex Nut | |
| 6 | Cartridge | |
| 7 | Cartridge Base | |
| 8 | Body | |
| 9 | O-Ring | |
| 10 | Connector | |
| 11 | O-Ring | |
| 12 | Brass Outlet Tub | |
| 13 | PlasticGasket | |
| 14 | O-Ring | |
| 15 | Brass Connector | |
| 16 | PlasticRing | |
| 17 | Bracket | |
| 18 | Silicon Tube | |
| 19 | Hose | |
| 20 | Brass Connector | |
| 21 | Check Valve | |
| 22 | Aerator Gasket | |
| | | |

| Part No | Description |
|---------|-----------------------------|
| 23 | Plastic Ring on the Bracket |
| 24 | Shower Body |
| 25 | Inside part of the Shower |
| 26 | Aerator |
| 27 | Base Ring |
| 28 | Base Ring Gasket |
| 29 | Fixing Triangle Board |
| 30 | Fixing Rubber Gasket |
| 31 | Fising S.S Gasket |
| 32 | FixingTub |
| 33 | Fixing Nut |
| 34 | Flexible Hose |

| Shower Hose Parts | | | |
|-------------------|-----------------|--|--|
| Part No | Description | | |
| 1 | O-Ring | | |
| 2 | Brass Connector | | |
| 3 | Nut | | |
| 4 | Spare Parts | | |
| 5 | Inside Tub | | |
| 6 | Nylon Yard | | |
| 7 | Brass Connector | | |
| 8 | O-Ring | | |

4