


PLUMBING GUIDE

If you do not want to cut out this template, you can download and print a copy online at: www.tmuk.net

Please ensure this cutter guide is printed at actual size. Prior to using this guide, check size matches against a 10p coin.

10p Coin



TEMPLATE AND WASTE GUIDE

Please read the important information below first, and follow the full 'Fitting Instructions'. Use the template guide ONLY to cut out the waste area. This will ensure minimum stress to the shower tray. Failing to do so, may weaken the shower tray and cracking may occur.

1. Place the shower tray in the required position on the floor.
2. Mark out the center point of the tray waste hole with a cross '+'.
3. Move the tray to a safe location to prevent accidental damage.
4. Cut out the template.
5. Position the template using the cross mark to align with the cross already marked on the floor (see fitting instructions).
6. Ensure the position of the template aligns correctly with the plumbing waste outlet.
7. With a pencil, mark around the template onto the floor.
8. Cut out the marked floor area with the correct tools.
9. Ensure that the hole is not cut larger than the template provided, as this can weaken the tray support.

WOOD FLOOR

It is essential that all flooring is properly secured, ensuring there is no movement or flex. Any joins in the flooring that are not supported by a joist must be supported by a separate noggin. Any flooring that flexes between joists MUST also be supported by additional noggins.

Ensure that flooring around the waste hole is fully supported by noggins. There must be no floor movement around the cut hole.

See fitting instructions for detailed illustrations and information.

WASTE UNIT INSTRUCTIONS - TWISTO Ø90

- Only use the waste unit provided. Fitting an alternative waste unit will compromise water flow.
- It is strongly recommended that a qualified plumber completes the waste unit installation and final plumbing.
- It is recommended that there should be a 25cm of straight outlet pipe before any bends are added.
- To join the outlet pipe to waste unit, use solvent weld. Test for leakage by pouring approximately 2 litres of water into waste unit prior to the final fix.
- Locate plastic flange onto waste unit with the securing screws supplied – Do not over-tighten the screws, only turn until the flange is secure. Over-tightening the screws may cause damage to the shower tray.
- It is essential that the fall angle of the waste pipe is maximised. Fall must be a MINIMUM of 2% to ensure adequate water flow.
- For trouble shooting and Q&A's, please visit www.wirquin.com

